

PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI	FT. LBS.	N-m	2HP
1000	162	220	
1200	180	244	
1400	214	290	
1600	265	359	
1800	299	405	
2000	335	454	
2200	369	500	
2400	401	544	
2600	436	591	
2800	471	639	
3000	505	685	
3200	539	731	
3400	574	778	
3600	610	827	
3800	643	872	
4000	678	919	
4200	712	965	
4400	747	1013	
4600	782	1060	
4800	817	1108	
5000	852	1155	
5200	886	1201	
5400	920	1247	
5600	955	1295	
5800	991	1344	
6000	1025	1390	
6200	1058	1434	
6400	1094	1483	
6600	1130	1532	
6800	1164	1578	
7000	1197	1623	
7200	1234	1673	
7400	1268	1719	
7600	1303	1767	
7800	1337	1813	
8000	1374	1863	
8200	1406	1906	
8400	1441	1954	
8600	1475	2000	
8800	1510	2047	
9000	1546	2096	
9200	1581	2144	
9400	1615	2190	
9600	1651	2238	
9800	1685	2285	
10000	1714	2324	